



OWNER'S MANUAL

AIR PURIFIER

For safe and easy use of the product please read the manual before use.

Please keep the warranty also included in a safe location.

This appliance is an indoor home appliance for use only at home.

Do not use this appliance for commercial, experimental or industrial purposes.

Model : AeroFurniture

EN ENGLISH



MFL71825221
Rev.04_060723

www.lg.com

Copyright © 2023 LG Electronics Inc. All Rights Reserved.

Table of Contents

SAFETY INSTRUCTION

04 Please Read Before Using the Product

04 Safety Symbols and their Meanings

04 WARNING

05 When handling the power plug and the power cord

06 When installing the product

07 When using the product

08 When using the UVnano function

08 CAUTION

08 When installing the product

09 When using the product

09 When disposing of the product

Using LG ThinQ

10 LG ThinQ Application

10 Installing the Application and Registering the Product

10 Before using LG ThinQ Application

11 Wireless Module Specifications

11 Upgrading the Product

11 Open Source Software Notice Information

OVERVIEW

12 Examining the Appearance of the Product

12 Front

13 Table

14 Filter

15 Accessories

16 Installing and Getting Ready

16 Assembling the Product

17 Removing the Protective Vinyl from the Filter

18 Selecting the Installation Site

18 Moving the Product

19 Replacing the Table and the Table Top

USING

21 Exploring the Control Panel

21 Controlling the Air Purifier

22 Operating the Air Purifier

22 Things to Know before Operation

22 Standby On/Off

22 Adjusting the Speed

23 Using Add-ons

23 Setting the Brightness of Mood Light

23 Using UVnano

24 Charging a Smart Device

25 Overall air quality

25 Understanding Overall Air Quality

MAINTENANCE

26 Maintaining and Cleaning the Product

26 Cleaning the Exterior of the Product

27 Cleaning the PM1.0 Sensor

28 Frequency of Cleaning and Filter Replacement

28 Notifications on the Status Panel

29 Cleaning the Filters

29 Replacing the Filters

29 Filter Replacement Alert Reset

30 Storing

30 Storing the Product

This manual may contain images or content different from the model you purchased.
This manual is subject to revision by the manufacturer.

THINGS TO CHECK BEFORE REPORTING A MALFUNCTION

31 Diagnosing a Failure

- 31 Diagnosing the Cause of the Malfunction with the LG ThinQ Application

32 Troubleshooting

- 32 Before Calling for Service
- 32 Operation
- 33 Status Panel
- 33 Odor
- 34 LG ThinQ

35 Product Specifications

- 35 Specifications Guide

36 Warranty

SAFETY INSTRUCTION

Please Read Before Using the Product

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance.

The guidelines are separated into 'WARNING' and 'CAUTION' as described below.

Safety Symbols and their Meanings



This symbol is displayed to indicate matters and operations that can cause risk. Read the text marked with this symbol carefully and follow the instructions in order to avoid risk.



WARNING

This indicates that failure to follow the instructions can cause serious injury or death.



CAUTION

This indicates that failure to follow the instructions can cause minor injury or damage to the product.

General users can access the device.

WARNING



WARNING

To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:


Children in the Household

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.


When handling the power plug and the power cord

⊘ PROHIBITIONS

- Do not touch the power plug with wet hands.



- Do not damage the power plug or the power cord. Do not damage, extend, place near high temperatures, excessively bend, twist, place heavy objects on top of, or tie a knot in the power cable.
- Do not connect the power plug to a multi-outlet (attached type), a plug adapter, or other accessories with no grounding cable.
- Do not press the power plug on the back of the product or plug it in backwards.



- Remove the power plug from the power outlet when cleaning the product or replacing the product filter.
- Do not repeatedly connect and disconnect the power plug.
- Do not disconnect the power plug during operation.

⊘ COMPLIANCE

- This product is for use with 220-240V only. Be sure to connect the power plug to a 220-240V outlet with a grounding terminal.
- If you wish to use a multi-tap, use a multi-tap (portable type) with a ground terminal with a current capacity of 20A or more. Connect only this product to the multi-tap.
- When installing a new product, use a newly purchased multi-tap if possible, and periodically check the condition of the wire sheath and plug connection.
- If there is moisture or dust on the power plug, remove it completely and then plug into the outlet firmly.
- When pulling out the power plug from an outlet, hold the power plug, not the power cord.
- Disconnect the power plug during thunderstorms or lightning or when not using the product for an extended period.
- Do not allow your pet animals to nibble the power cord.
- If moisture penetrates inside the product, disconnect the power plug and contact an LG Electronics Customer Information Center.
- If the power cord or power plug is damaged, or the holes in the power socket are loose, stop using the product immediately and contact an LG Electronics Customer Information Center.


When installing the product

⊘ PROHIBITIONS

- Do not install the product in the following places:
 - Places exposed to water or rainwater, or places where there is high humidity.
 - Places with a lot of dust or extreme temperature changes (outdoors, vinyl greenhouses, etc.).
 - Places with flammable gas leaks or with a lot of industrial oil or metallic dust present.
 - A place with an uneven or inclined floor.
 - On top of a mat or a blanket.
 - Places under direct sunlight or where there are heating appliances.
- The product should not be disassembled, repaired, or modified unless the work is done by a service engineer from an LG Electronics Customer Information Center.
- Do not allow the product or power cord to come into contact with any hot surface.

⊘ COMPLIANCE

- Install the product in a position which allows the power plug to be easily removed from the power outlet.
- Dispose of product packaging materials (vinyl, Styrofoam, etc.) immediately following installation. Children can choke on packaging whilst playing with it.



- To reduce the risk of fire, make sure that fabrics, curtains, or other combustible materials are kept at least 1 m away from the air outlet.

When using the product

PROHIBITIONS

- Do not clean the product with brushes, cloths, or sponges that have rough surfaces or which are made of metallic materials.
- Only an authorized repair person from an LG Electronics Customer Information Center should disassemble, repair, or modify the product.
- Do not use or store the product near flame, combustibles (ether, benzene, alcohol, medicines, LP gas, combustible sprays, insecticides, air fresheners, cosmetics, etc.) or flammable materials (candles, lamps, etc.).
- Do not cover cord with throw rugs, runners, or similar coverings.
- Do not move the product while it is operating.
- Do not place hands, metallic objects (sticks, pins) or foreign objects in the inlet or outlet.
- Do not expose the product to impact shock.
- Do not use damaged accessories.
- Do not put flammable substances into the product.
- Do not operate the product while the cover is open.
- Do not clean the product while power is connected.
- Be aware that the smart device may overheat if it leaves the center of the wireless charging unit.

COMPLIANCE

- If the appliance is immersed in water, stop using it and contact an LG Electronics Customer Information Center.
- If there is a gas leakage (isobutane, propane, LNG, etc.), do not touch the product or power plug and ventilate the area immediately.
- If the product emits an abnormal sound, odor, or smoke, unplug the power plug immediately and contact an LG Electronics Customer Information Center.
- Do not allow animals or pets to chew on the power cord.
- Do not allow children to climb on or play with the appliance.
- Be careful not to let body parts get caught in the product when removing product components and/or reassembling them.

When using the UVnano function

This is only for models with the UVnano function. Models with the UVnano function are equipped with a UV-C lamp (UV LED) inside the product.

PROHIBITIONS

- Be careful as UV-C may be released to the outside due to unintended use of the product or damage to the product. UV-C can harm the eyes and skin even with minimal exposure.
- Do not operate the UV LED outside the product.
- Do not touch or clean the product while the UVnano function is operating.
- Do not remove the UV hazard label from the inside of the product. UV-C may be emitted from the UV LED.
- The UV LED is not a part that needs cleaning, so do not clean the UV LED or parts displaying the UV hazard label separately.
- The UV LED is a non-user-replaceable part. Do not replace it yourself.
- If the UV LED is damaged, do not operate it.

COMPLIANCE

- The product must be turned off at the main power switch and unplugged before the installation, inspection, repair, or replacement of the UV LED.
- Installation, inspection, repair, or replacement procedures related to UV LEDs, must use the UVnano module provided by LG Electronics and contact an LG Electronics Customer Information Center.
- If the UV LED is damaged or it needs to be replaced, stop using it and contact an LG Electronics Customer Information Center.

CAUTION

CAUTION

To reduce the risk of minor injury to persons, malfunction, or damage to the product or property when using this product, follow basic precautions, including the following:

When installing the product

PROHIBITIONS

- Do not install the product in an unstable place or in a place with severe vibration.
- Do not install the product above the user's eye level.
- Do not install the product inside a vehicle (camping vehicle), a ship, or an airplane.
- When moving the product, do not push or drag it by tilting.
- Do not place the product near a TV or audio system.
- Do not install or use the product in a location where there is a risk of explosion.

COMPLIANCE

- Install the product in a location with a firm and level floor.
- Install the product in a space with no threshold.
- When assembling the table or the table top, do not let other objects come between them.

When using the product

PROHIBITIONS

- Do not use the product for a long time where voltage is unstable.
- Do not use the product to remove toxic gases such as carbon monoxide.
- Do not use the product for ventilation purposes.
- Do not place obstacles near the air inlet or outlet of the product.
- Do not use the product near curtains.
- Do not use the product for special purposes or in areas that are used to house animals, preserve plants, keep precision instruments, or art works, etc.
- Do not climb or sit on the product.
- Do not operate the product with wet hands.
- Do not use the product lying down.
- Do not lean against the product.
- Do not use the filter for purposes other than those for which the product is designed.
- If the product is stained with soapy water, cosmetics, chemicals, air fresheners, disinfectants, etc., wipe off immediately with a soft cloth or wet wipe.
- Do not clean the product with strong detergents such as solvents.
- Do not place magnets or metallic objects on top of the wireless charging unit of the product.
- Do not place a hot object on the product.
- Do not place a heavy object on the product. (Recommended gross weight: 2kg or less)

COMPLIANCE

- Be careful not to let people (especially children) or animals climb onto the product or place objects (especially magnets or metallic objects, etc.) on top of the product.
- Do not clean the product with a brush, cloth, or a scouring pad that has a rough surface or is made of metal. Use only a soft microfiber cloth to clean the product.
- Be careful not to let the moisture emitted by a humidifier come into direct contact with the product.

When disposing of the product

COMPLIANCE

- Dispose of packing materials (vinyl, Styrofoam, etc.) safely so that they are unable to come into contact with children.

Using LG ThinQ

LG ThinQ Application


Installing the Application and Registering the Product

You can conveniently manage your LG home appliances anytime, anywhere by installing the **LG ThinQ** Application.


Before using LG ThinQ Application

This feature is only available on models with Wi-Fi function.


- 1 Turn off Data on your smart phone.
 - For Android phone users, turn off Mobile Data.
 - For iOS phone users, turn off Cellular Data.




- 2 Connect the smart phone to your Wi-Fi.
 - Do not select a Wi-Fi connection with **5G** in its name. This product does not support **5 GHz**.



- 3 Search for and install the **LG ThinQ** Application.
 - For Android phone users, search for and install the **LG ThinQ** Application from the Google Play Store.
 - For iOS phone users, search for and install the **LG ThinQ** Application from the Apple App Store.



- 4 Run the installed **LG ThinQ** Application and log in.
 - You can log in with an account that you already have or create an LG account and log in using that LG account.



- 5 Press the Add a Device menu (+). Please click the **Scan QR** button on the product selection screen or directly select and click the air purifier.
 - Register the product by following the instructions in the **LG ThinQ** Application.
 - When you press the **Scan QR** button, the model name and the manufacturer's serial number will be entered automatically in the additional information registration. (Check the QR attached to the product.)

NOTE

- The Wi-Fi name and password are on the wireless router. For Wi-Fi, **2.4 GHz** must be selected. The Wi-Fi module installed in the air purifier does not support **5 GHz**, so the air purifier cannot be connected to a wireless router if **5 GHz** is selected.



- WPA2 for the wireless router's authentication and encryption type is recommended.

- The connection quality of the wireless network may be affected by the surrounding wireless environment. If a problem arises in relation to the wireless network connection, please contact your Internet Service Provider.
- If you cannot connect the built-in Wi-Fi module of the air purifier to the wireless router, you can solve the problem as follows:
 - If a firewall is set on the wireless router, register it to the list of exceptions or turn it off before proceeding.
 - *If the name or password of an older wireless router includes special characters (★, □, ■, ♥, etc.), the product cannot be connected to the wireless router. Be sure to set the Wi-Fi name and password using English letters, numbers, or a combination of English letters and numbers.
 - *Older wireless routers do not support Unicode (a standard character processing method designed to use all characters in the world) UTF-8.
- If the air purifier is too far away from the wireless router, the signal strength decreases. If the signal is weak, registering the product may take a long time or even fail.
- If you have changed the password of the wireless router or your Internet Service Provider, delete the registered air purifier from the **LG ThinQ** Application and register it again.
- The contents of this manual may differ depending on the version of the **LG ThinQ** Application and may be changed without prior notice to users.

Wireless Module Specifications

Radio equipment can cause radio interference, and it cannot be used for services related to human safety.

Wi-Fi

Model	LCWB-001
Frequency Range	2412 MHz - 2472 MHz
Output Power (Max)	IEEE 802.11b: 18.14 dBm IEEE 802.11g: 17.38 dBm IEEE 802.11n: 16.13 dBm

Bluetooth

Frequency Range	2402 MHz - 2480 MHz
Output Power (Max)	7.03 dBm

Wireless Charge Module

Model	EAT65191501
Frequency Range	Output Power (Max)
150 kHz – 205 kHz	≤ 13.5 dBuA/m @ 10m
110 kHz – 150 kHz	≤ 66 dBuA/m @ 10m

Upgrading the Product

- When a new function that can be upgraded is available, **UP** will turn on the status panel when you turn on the product.
 - From the menu on the **LG ThinQ** Application, you can upgrade the function by pressing **Feature Updates**.
 - This function is available after registering the product in the **LG ThinQ** Application.

Open Source Software Notice Information

To obtain the source code that is contained in this product, under GPL, LGPL, MPL, and other open source licenses that have the obligation to disclose source code, and to access all referred license terms, copyright notices and other relevant documents, please visit <https://opensource.lge.com>.


LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid to anyone in receipt of this information for a period of three years after our last shipment of this product.

OVERVIEW

Examining the Appearance of the Product

Front



1 Status panel

- Use it to check the settings of the product and the air condition.

2 Wireless charging unit

- Use it to charge a smart device enabling wireless charging.

3 Table top

- This table top can be separated and replaced.

4 UVnano LED (limited to applicable models)

- Remove the harmful bacteria at internal fan of the air purifier.

5 Filter

- Minimizes allergens, fine particulates, possible sources of sick house syndrome, smog, and other odors.

6 Sensor

- PM1.0 (super ultra-fine particles) Sensor : Detects the concentration levels of dust.

7 Smart Diagnosis

- If the product malfunctions, use Smart Diagnosis to check the product status.


8 Air inlet (cover)

- Air goes into the air purifier through the inlet.
- The front and rear covers may be removed separately.

9 Air outlet

- It discharges purified air through the filter.

Table



1 Mood Light

- Use it to adjust the brightness of mood light.

2 Table Base Separation Button

- The table can be separated by pressing the buttons on both sides at the same time.

3 Control Panel

- Use it to set the product functions (Standby On/Off, Speed, Mood light, etc.).

4 Table Joint

- This is the part where the main body and the table are combined.


5 Table Top Fixing/Separation Device

- Use it to fix or separate the table top after assembly.

✓ NOTE

- The table and the table top (circle type/track type) can be purchased from a nearby LG Electronics Customer Information Center or visit the website (www.lg.com).

Filter



1 Deodorizing Care Filter

- Minimizes odors from the bathroom, cigarettes, food and other common sources.

2 Aero Series V Filter

- Minimizes PM1.0 and cigarette smoke from the air.

3 Filter Handle

- Use it when inserting or removing the filter from the product.
- Position the side with the handle facing up.

4 Ultra Fine Filter

- The Ultra Fine Filter is attached to the outer surface of the filter, and primarily removes large particles of living dust from the air.




CAUTION

- The filter is attached, so do not forcibly separate the filter.
- Do not throw or use the filter for other purposes.

NOTE

- A slight odor may be emitted from a new filter at the start of use following purchase. The odor will disappear after a day or so of using the product, so you can use it without concern.
- The frequency of cleaning and filter replacement may vary depending on the operating environment and usage time.
- The filter can be used for up to 1 year. The more polluted the indoor air, the shorter the life of the filter.
- If there is excessive odor in the room, first remove odor (gas) in the room through ventilation, and use the product only for removing the remaining odor following ventilation.
- If the air purifier is used after not having been used for a long time and there is an odor, you can reduce the odor from the filter by operating it on high mode for fan speed in a ventilated area.
- The filter may emit an odor when used continuously in a humid environment or where moisture from a humidifier is absorbed into the filter. If an odor is generated due to moisture, dry the filter in sunlight before use.
- Using an ultrasonic humidifier and air purifier at the same time may drastically reduce the filter life due to the lime contained in the humidifier spray.
- In cases of a humidifier and an air purifier being used at the same time, it is recommended that a natural vaporization humidifier be used.
- Carbon monoxide (CO) is a harmful gas that is mainly introduced from the outside, and cannot be removed by a filter.
- Keep the windows or doors closed while using the product. However, if you operate the product for a long time in a closed space, the carbon dioxide concentration may rise. So be sure to ventilate indoor spaces regularly.
- The deodorization function of the air purifier operates by trapping the odor (gas) in the filter. If you use the product for a long time in a room with excessive odor, the performance of the filter may decrease significantly.
- If the surrounding odors permeate the filter and the filter smells when you use the air purifier, it's time to replace the filter, so replace the filter with a new one. Filters are consumable products, and the replacement of filters that occurs during use has a cost to the user even during the free warranty period.
- Filters can be purchased from a nearby Customer Information Center or visit the website (www.lg.com).

Accessories**1**


- 1** Owner's Manual

Installing and Getting Ready


Assembling the Product

Remove the packaging vinyl and the filter vinyl from the product before using the product.

- 1 Remove the main body and the table from the box and remove the protective vinyl.
- 2 Prepare the main body and the table as shown in the figure below.
 - The side with the **LG logo** is the front of the product.
 - Based on the top side of the table, on the left side from the **LG logo** is the status panel and on the right side from the **LG logo** is the wireless charging unit.



- 3 Assemble the table to the main body according to the direction.



⚠ CAUTION

- Assemble the table to the main body until a clicking sound is heard.
 - If it is not assembled properly, the product won't operate.
- Pay attention to the assembly directions when assembling the table to the main body.
 - Failure to do so may cause malfunction or product failure.
- If power is connected to the main body without assembling the table, the product won't operate.


✔ NOTE

- Assemble the track type in the same way as the circle type.


Removing the Protective Vinyl from the Filter

Remove the fixing tape and the protective vinyl from the filter before using the filter.


- 1 Based on the front of the product, hold and gently pull both sides of the air inlet (cover) to separate it.
 - The side with the **LG logo** at the center of the product is the front of the product.




- 2 Remove the filter and its protective vinyl.
 - When removing the packaged filter, separate it from the protective vinyl.



- 3 Install the filter into the product.
 - Make sure that the side with the filter handle is facing upward.



- 4 Insert the fixing part on both sides at the bottom of the cover into the fixing groove in the bottom of the product, and then close the cover.




CAUTION

- Be sure to remove the protective vinyl from the filter before using the product.
- When installing the filter, pay attention to the direction of the filter.
 - Failure to do so may cause malfunction or product failure.
 - The part with the filter handle is the top side.

Selecting the Installation Site


- Install at a distance of at least 1m from a wall.
 - If there is not enough space for air to be taken in, performance of the air purifier may be reduced.



- The performance of the product may differ depending on the operating environment (considering factors such as temperature and humidity).
 - At humidity levels of between 40% ~ 70%, the product's guaranteed performance standards can be achieved.
- Do not install the product in a place exposed to direct sunlight or near lighting fixtures emitting strong light.
 - This may cause product discoloration.

Moving the Product

- When moving or storing the product, make sure that the power cord does not touch the floor by wrapping the power cord around the lower part of the product.
 - Otherwise, it may damage the power plug or scratch the floor.
- When carrying and moving the product
 - Hold the bottom of both sides of the product table and move it safely.



⚠ CAUTION


- Move the product after checking that the table is properly fixed.
- Do not hold the outside cover of the product in order to move the product. The cover may open accidentally, causing the product to drop.
- When holding the bottom of the table, be careful not to press the **Table Base Separation** button. Doing so may separate the table from the main body and cause it to fall.
 - If the product is dropped, it may cause injury or product failure.

Replacing the Table and the Table Top

Replacing the Table

Remove the packaging vinyl from the table before using it.

- 1 Separate the table by pulling it up while pressing the **Table Base Separation** button on both sides at the bottom of the table at the same time.



- 2 Assemble a new table into the main body.
 - Read "Assembling the Product".


⚠ CAUTION

- When separating or assembling the table, be careful not to let water or foreign objects enter into the table joint.
- Do not separate the table while operating the product.
- Use the **Table Base Separation** button only for replacing the table.
 - Using the button incorrectly may cause injury or product failure.


Replacing the Table Top

Remove the packaging vinyl from the table top before using it.

- 1 With the table separated, disassemble the **Table Top Fixing/Separation** device from both sides of the table as shown in the figure below.




- 2 As shown in the figure below, first lift the joint unit of the wireless charging unit up to disassemble it, and then lift up the table top to separate it.




✔ NOTE

- Disassemble 6 joint units for the circle type and 10 joint units for the track type.



- For the track type, first lift the joint unit of the wireless charging unit up to disassemble it, and then lift up the table top to separate it.

- 3 Place a new table top at the position of the wireless charging unit correctly, assemble the joint unit and fix the **Table Top Fixing/ Separation** device as shown in the figure below.



✓ NOTE

- It applies in cases where separate accessories are purchased.
- When fixing the table top, close the fixing device until a click is heard.



CAUTION


- Be careful not to pinch your fingers or nails when separating or assembling the table.
 - Failure to do so may cause injury.
- When separating the table, be careful not to let the table bump into any part of your body (face, chest, etc.).
- Use the **Table Top Fixing/Separation** device only for replacing the table top.
 - Using the device incorrectly may cause injury or product failure.

USING

Exploring the Control Panel

Controlling the Air Purifier

Status Panel (Top side of the table)



1 Add-on Display

Icon	Description
	It is displayed when Wi-Fi connection is established, enabling remote control.
	It is displayed when a new function that can be upgraded becomes available.

2 Air quality Light


- Indicates air quality condition by color (green, yellow, orange, red) according to PM10/PM2.5/PM1.0 concentrations.
- In Sleep mode, the air quality light is turned off.

3 Speed Light

- Indicates the speed set among Auto, Low, Middle, High and Sleep.

Speed	Display	Description
Auto		3 LEDs circulating
Low		1 LED ON
Middle		2 LEDs ON
High		3 LEDs ON
Sleep		1 LED ON (50% of brightness of Low)

Control Panel (Bottom side of the table)



1 Standby On/Off button

- Use it to turn the product on or off.

2 Speed button

- Use it to set the fan speed.

3 Mood Light button

- Use it to set the brightness of mood Light.

NOTE


- You can use additional functions by pressing the buttons on the control panel for 3 seconds.

Press the button for 3 seconds	Additional functions
	Wi-Fi connection (Remote operation)
	Smart Diagnosis
	Cancel Filter Replacement Alert

Operating the Air Purifier

Things to Know before Operation


※ The control panel is located below the table



Standby On/Off

Turns the product on and off.

- Press the **Standby On/Off** button to start operation.




NOTE

- If you stop operation and then resume, it will start cleaning with the mode you last selected.
- If the product is unplugged or a power failure occurs during operation, the most recently used mode (speed, light) will be memorized.

Adjusting the Speed

You can adjust the fan speed from the air purifier.

- When you press the **Speed** button during product operation, the speed changes in the order of Auto → Low → Middle → High → Sleep.




NOTE

- The higher the speed, the higher the purification rate in the space.
- When Auto is set, the speed will be controlled automatically according to the contamination level of the indoor air.
- When Sleep is set, the air quality light will be turned off.

Using Add-ons

Setting the Brightness of Mood Light

You can adjust the mood light brightness.



- When you press the **Mood Light** button during product operation, the brightness of Light under the table base changes in the order of **ON** → **ON at Middle brightness** → **OFF**.

✓ NOTE

- OFF is set as the initial step in mood light.
- Mood light brightness can be controlled also when **Sleep** is set for the fan speed and operation has stopped.

Using UVnano

- ※ The relevant contents apply only to models with the UVnano function. It sterilizes the fan inside the air purifier to circulate cleaner air.
- You can change the UVnano settings using the **LG ThinQ** Application.
- The UVnano function is enabled by default when using the product for the first time.

✓ NOTE


- UVnano is a compound word of "UV LED" that reduce harmful bacteria and "nanometers", as in the ultraviolet wavelength unit.
- The UV LED is not a part that needs cleaning, so do not clean the UV LED or parts displaying the UV hazard label separately.
- If the UV LED is damaged, do not operate it.
- To clean the product or replace the filter, unplug the product.

⚠ CAUTION


- This appliance contains a UV-C emitter.
- Unintended use of the appliance or damage to the housing may result in the escape of dangerous UV-C radiation.
- UV-C radiation may, even in little doses, cause harm to the eyes and skin.
- Appliances that are obviously damaged must not be operated.
- Do not replace the UV-C emitter by the user.

Charging a Smart Device

- Placing a smart device supporting wireless charging on the charging area with the power connected to the product, will see charging begin.



- Place the smart device in the center of the wireless charging unit.
 - If the smart device wireless charging unit leaves the center of the wireless charging unit, it may not be charged smoothly.
 - The farther away from the center the smart device is, charging will be less efficient, or may temporarily stop repeatedly.



CAUTION

- If there is a coin or other metallic object between the wireless charging unit and the smart device, be sure to remove it before using the unit.
 - Wireless charging may stop due to metallic objects.
 - Metallic substances may become hot during the charging process, resulting in low-temperature burns.

NOTE

- Each smart device has different wireless charging characteristics, so check the contents regarding wireless charging in the smart device's manual before using wireless charging.
- If the temperature of the wireless charging unit is too high during charging, charging will stop.
 - In order to protect the smart device, charging stops when the temperature reaches a preset temperature, and when it falls under the set temperature, the charging function will resume.
- Charging may fail because of a smart device's protective case.
 - Charging may not be possible due to metal or a ring holder.
 - Depending on the thickness of the protective case, charging may be delayed or interrupted.
 - When using a wallet/card case, charging may be delayed or interrupted because of a card or the thickness of the case.
- Placing magnetic materials, such as a credit card, near the wireless charging area or the charging area may damage the information contained therein.
- When you place a smart device in the charging area, charging will begin 3 to 5 seconds later.
 - Charging time may vary depending on the smart device manufacturer.
 - If charging does not begin 3 to 5 seconds later, lift the smart device and change its position.
- Using wireless charging in an area where the network signal strength is weak may deteriorate the smartphone's network performance.
- If you connect a wired charger to a smart device that is currently being charged wirelessly, the wireless charging function will be disabled.

Overall air quality

Understanding Overall Air Quality

Overall air quality is categorized using 4 levels, ranging through green, yellow, orange and red depending on the contamination levels of the air based on the concentration of dust.

Color	Overall air quality	Concentration of PM ($\mu\text{g}/\text{m}^3$)		
	State	PM10	PM2.5	PM1.0
Red	Poor	255 or more	56 or more	56 or more
Orange	Unhealthy	155 ~ 254	36 ~ 55	36 ~ 55
Yellow	Moderate	55 ~ 154	13 ~ 35	13 ~ 35
Green	Good	54 or less	12 or less	12 or less

- The dust concentration can be determined by the color displayed by the air quality light.
- The color that appears in the air quality light is determined based on the condition of the worst dust concentration level among dust concentration levels.

✓ NOTE


- The level of dust concentration for LG Electronics products is the result expressed after measuring the quantity of dust using an optical method and converting the measurement into fine dust concentration.
- The dust concentration displayed on the product may be different from the measurement standards of other instruments and other products.
- The dust concentration criteria for PM1.0 were set based on the same criteria as PM2.5. (Company Standard)
- When using different or identical products in the same space, air circulation may cause differences in the level of dust concentration.
- The flow around the dust sensor interferes with the normal operation of the dust sensor, so the level of dust concentration displayed may differ from the actual level of dust concentration.
- If the product is used in the following environments, the level of dust concentration displayed may differ from the actual value:
 - Around fabric sofas and beds, around shaggy carpets, when arranging blankets/clothes, when vacuum cleaners are in use, insects and pet areas, high humidity areas;
 - Places where outside air enters, such as construction sites, roadsides, factories or around entrances, windows and ventilation openings;
 - Where there are products that generate steam and fine particles (humidifiers, cookware, sprays, etc.);
 - Even if dust is generated by activities such as mopping or cleaning, the sensor may not respond if dust larger than fine dust is generated, but the dust will be removed by the filter.

MAINTENANCE

Maintaining and Cleaning the Product

Cleaning the Exterior of the Product

- 1 Remove any dust from the air inlet (cover) using a vacuum cleaner.
- 2 Wipe the exterior of the table top with a soft cloth.



NOTE

- Refer to the following contents for cleaning the table top.
 - If the product is dusty or stained, wipe with a clean microfiber cloth or wet wipe for cleaning.
 - If the product is stained through being touched by hands stained with cosmetics, wipe the substance off with a microfiber cloth moistened with a face wash (foam cleanser, etc.).


CAUTION

- Do not clean the product with an alkaline detergent.
- Do not wipe the product surface using sulfuric acid, hydrochloric acid, or an organic solvent (thinner, kerosene, acetone, etc.) or attach stickers to the product. This may damage the product surface.
- Be careful not to let water get inside the product.
- If the product is stained by soapy water, cosmetics, chemicals, air fresheners, disinfectants, etc., wipe the substance off immediately with a soft cloth or wet wipe.
- Do not let a sharp object such as a key or a knife come into direct contact with the surface of the product.
 - Failure to do so may result in damage to the product's surface.
- Do not let ballpoint pens, crayons, colored pencils, etc., come into direct contact with the surface of the product.
 - Failure to do so may result in staining or damage to the surface of the product.


Cleaning the PM1.0 Sensor

The PM1.0 (super ultra-fine dust) sensor is the device detecting fine dust and large dust contamination levels, so it is recommended to clean the lens periodically, at least once every 2 months.


- 1 Based on the front of the product, hold and gently pull both sides of the air inlet (cover) to separate it.
 - The side with the **LG logo** at the center of the product is the front of the product.




- 2 Push the sensor cover up.



- 3 Put a little water on a cotton swab to wipe the lens, and wipe away any remaining moisture with a dry cotton swab.




- 4 Close the sensor cover.



NOTE

- Do not wipe the sensor with anything wet other than something that has been dampened using only water.
 - Doing so may cause product failure.
- When opening or closing the sensor cover, a sound may be heard as a result of friction.


Frequency of Cleaning and Filter Replacement

Type	Cleaning frequency	Replacement cycle
 Filter	Ultra-fine Filter If it is contaminated, use a vacuum cleaner or a soft brush to clean it.	1 year

✓ NOTE

- The operating environment and operating hours of the product may affect the cleaning frequency.
- If the product is not cleaned in accordance with the recommended cleaning frequency, bad odors or poor performance may result.
- A filter is a consumable item. Therefore, when they have reached the end of their effective lifespan, even during the warranty period, new replacements will need to be purchased. Filters can be purchased from a nearby Customer Information Center or visit the website (www.lg.com).
- If the surrounding odors permeate the filter and the filter smells when you use the air purifier, it's time to replace the filter, so replace the filter with a new one. Filters are consumable products, and the replacement of filters that occurs as a result of use comes at a cost, even during the warranty period.
- Since paper instead of plastic is used for the top and bottom of the filter, scratches may occur on the top and bottom of the filter if the filter is repeatedly inserted into or removed from the product.
- Even if scratches occur on the top and bottom of the filter, there is no problem using it.

Notifications on the Status Panel


Notification	Description	Corrective action
	3 LEDs blinking at the same time	It occurs when it is time to replace the filter.

✓ NOTE


- The filter replacement alert is displayed in consideration of the product operating time, and the replacement cycle may vary depending on the usage time and environment.

Cleaning the Filters

- 1 Separate the front and rear covers from the product.
 - Based on the front of the product with the **LG logo**, hold and gently pull both sides of the cover on top of the air inlet (cover) to separate it.



- 2 Remove dust surrounding the Aero Series V Filter from the ultra-fine filter with a vacuum cleaner or soft brush.




⚠ CAUTION

- Do not wash the Deodorizing Filter or the Aero Series V Filter with water. This will shorten the filter's life.
- When using a vacuum cleaner, be careful not to damage the ultra-fine filter.
- Be careful as the filter may be damaged if it is covered with liquid.

Replacing the Filters

Remove the front and rear covers of the product and pull the handle to replace the filter.


- To avoid polluting the surroundings when replacing the filter, place newspaper on the floor before you remove the filter.



Filter Replacement Alert Reset

The filter replacement alert on the status panel will be canceled and the replacement notification time will be initialized.

- Press and hold the **Standby On/Off** and **Mood Light** buttons on the control panel at the same time for 3 seconds.



✔ NOTE


- A notification is displayed when the filter needs to be replaced.
- Use when replacing with a new filter.

Storing

Storing the Product

If the product will not be used for a long period of time, store it in a dry and shaded place.

- 1** Operate the product for at least 1 hour on a sunny day.
 - This removes moisture and prevents mold from building up inside the product.
- 2** Turn off the power and unplug it from the electrical outlet.
 - Wind the power cord around the bottom of the product and insert it into the base.
- 3** Package the product to prevent dust or foreign substances from entering the product. Store the packaged product in a dry shaded place.



CAUTION

- Do not store the product in a humid place or in a place exposed to direct sunlight. This may cause the product to become deformed, malfunction, or generate odors.

THINGS TO CHECK BEFORE REPORTING A MALFUNCTION

Diagnosing a Failure

Diagnosing the Cause of the Malfunction with the LG ThinQ Application

This is a function that can diagnose the cause of product failure.


NOTE

- Service may be suspended due to external factors (disabled use of Wi-Fi, disconnected Wi-Fi, App Store policy, App unavailable, etc.), not LG Electronics' negligence.
- This may change without prior notice, and the service method may vary depending on local circumstances.


Diagnosing a Failure with a Signal Sound

In case of continuous **Smart Diagnosis** failure using the Application, press the '**Go to Audible Diagnosis**' button and follow the instructions displayed.

- 1 Press and hold the **Speed** and **Mood Light** buttons at the same time for 3 seconds to execute the **Smart Diagnosis** function.



- 2 Place the smart phone near the product.
 - Point the microphone on the smartphone toward the front of the product.



- 3 When data transmission is complete, the **Smart Diagnosis** result will be displayed on the **LG ThinQ** Application.

NOTE

- For accurate diagnosis, do not move the smart phone away from the product until the beeping stops.
- Carry out the **Smart Diagnosis** in a quiet environment.

Troubleshooting

Before Calling for Service

Please check the following before you contact the service center.
If the problem persists, contact your local service center.

Operation

Symptoms	Causes and Solutions
The product does not power on.	Is the power plug disconnected? <ul style="list-style-type: none"> Connect it to an outlet correctly.
	Are you using a voltage of 220-240V? <ul style="list-style-type: none"> The rated voltage of the product is 220-240V. Check the voltage marked on the outlet.
	Did the electricity get cut off? <ul style="list-style-type: none"> Check the power to other products in the house.
	Are the main body of the product and the table assembled properly? <ul style="list-style-type: none"> Refer to "Assembling the Product" and assemble the main body of the product and the table properly.
A noise occurs and the fan speed is low.	Has dust accumulated in the ultra-fine filter? <ul style="list-style-type: none"> Clean the ultra-fine filter.
	Has dust accumulated in the filter? <ul style="list-style-type: none"> Replace the filter.
Air purification is not done properly.	Is the indoor pollution severe? <ul style="list-style-type: none"> Ventilate indoors before using the product.
	Has dust accumulated in the ultra-fine filter? <ul style="list-style-type: none"> Clean the ultra-fine filter.
	Has dust accumulated in the filter? <ul style="list-style-type: none"> Replace the filter.
	Are you using it in a place that is too spacious or too open? <ul style="list-style-type: none"> Use a product that suits the size of the room. Avoid well-ventilated places such as doors, windows, etc.
	Is there an obstacle nearby? <ul style="list-style-type: none"> Remove the obstacle.
	Is the product installed in a corner? <ul style="list-style-type: none"> Move the product and reinstall it.
Wireless charging is not available.	Did you place the smart device at the center of the wireless charging unit? <ul style="list-style-type: none"> If the smart device leaves the center of the wireless charging unit, it will not be charged.
	Is the smart device fitted with a protective case? <ul style="list-style-type: none"> Depending on the thickness of the protective case, charging may be delayed or interrupted. Charging may not be possible due to metal or a ring holder. When using a wallet type/card type case, charging may be delayed or interrupted because of a card or the thickness of the case.

Status Panel

Symptoms	Causes and Solutions
The air quality light is continuously red.	Does the color not change even if it is moved to a clean room? <ul style="list-style-type: none"> If the amount of odor is more than the capacity of the product, the display may not change. Remove the power plug from the outlet and reconnect after 1 minute.
	Did you use a spray near the product? <ul style="list-style-type: none"> Do not use a spray near the product.

Odor


Symptoms	Causes and Solutions
A strange odor comes out of the air outlet as well as the filter.	Did you purchase the product recently? <ul style="list-style-type: none"> This is the odor of activated charcoal, and is not harmful. This is similar to the odor you may experience in a brand new car. It will go away within a day following use.
	Is the product used in a place with a lot of smoke or odors? <ul style="list-style-type: none"> If the air purifier is operated after an air freshener, diffuser, or scented candle has been used, or interior work or wallpaper replacement have occurred, the filter may absorb and emit an odor. Ventilate the room first before using the product.
	Does the filter have a bad smell? <ul style="list-style-type: none"> The filter replacement cycle may vary depending on the usage environment. If there is an odor, replace the filter with a new one.
	Is it in an environment in which food is prepared? <ul style="list-style-type: none"> If you use the product for a long period of time where you cook or broil fish/meat, the filter lifespan may be significantly decreased. If possible, open a window for ventilation while cooking, and use the product to remove any odors left following ventilation.
	Is it a humid environment? <ul style="list-style-type: none"> The filter may emit an odor if used in a humid environment. Dry the filter in sunlight before use.

LG ThinQ

Symptoms	Causes and Solutions
The product and the smartphone cannot be connected through Wi-Fi.	Is the Wi-Fi password used to connect to the smart phone correct? <ul style="list-style-type: none"> Press the Settings button on your smart phone, and then find your Wi-Fi in the network list. Press and hold the button to select [Clear Network], and then proceed with product registration again from the beginning.
	Is your smart phone using mobile data rather than Wi-Fi? <ul style="list-style-type: none"> In the smart phone's settings, turn off Mobile Data, turn on Wi-Fi, and then register the product.
	Does the name(SSID) of the wireless router set correctly? <ul style="list-style-type: none"> The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
	Is the frequency of the wireless router not 2.4GHz? <ul style="list-style-type: none"> When connecting the product via Wi-Fi, only a 2.4GHz network can be used. Set the wireless router to 2.4GHz and then connect. To check the frequency of your wireless router, contact your Internet carrier or router manufacturer.
	Are the product and the wireless router too far apart? <ul style="list-style-type: none"> If the distance between the product and the wireless router is too great, the wireless signal may be weak, and the connection may not be smooth. Move the wireless router closer to the product.

Product Specifications

Specifications Guide



Model Name	AF20* Series
Power	AC 220-240 V~, 50 Hz
External dimensions (1 x 2 x 3)	275 mm x 275 mm x 550 mm

※ This product is not equipped with a gas sensor.

Warranty

Please apply glue and seal here

Fold here



LG Electronics Singapore Pte Ltd

(Customer Service Centre)

No. 99TD, Alexandra Road (Opposite PSA Building)

#01-14, Singapore 119972

MRT: Labrador Park station (Circle Line)

Tel: (65) 6512-0555 Fax: (65) 6479-5598

Operation Hours: Mon - Fri 0830 - 1800, Sat 0830 - 1400

Sun & P.H. closed

Website: www.lg.com/sg (Online warranty Registration)

(Please fill in the form in BLOCK letters)
(*are compulsory fields)

Personal Information

*Name: _____

*Gender: MALE / FEMALE

*Address: _____

*Postal Code _____

*Contact (Home) _____ (Mobile) _____

*Email: _____

Product Information

*Model _____

*Serial Number _____

*Purchase Date _____

DD/MM/YYYY

Note: Warranty is only valid with Dealer's Stamp & enclosed with a photocopy of the purchase receipt
Warranty is only valid when form is duly filled & send to LGE within 14 days from original date of purchase

Would you like to receive latest news and promotional updates from LG? Yes ☐ No ☐

Please apply glue and seal here

Fold here

Please apply glue and seal here

Dealer's Information



Dealer's Stamp

Invoice No: _____



LG Electronics Singapore Pte Ltd

(Customer Service Centre)
No. 991D, Alexandra Road (Opposite PSA Building)
#01-1/4, Singapore 119972
MRT: Labrador Park station (Circle Line)
Tel: (65) 6512-0555 Fax: (65) 6479-5598
Operation Hours: Mon - Fri 0830 - 1800, Sat 0830 - 1400
Sun & P.H. closed
Website: www.lg.com/sg (Online warranty Registration / E-appointment service)

Customer's Copy

Warranty Card No : **CE**

Personal Information

*Name: _____
*Gender: MALE / FEMALE
*Address: _____
*Postal Code _____
*Contact:(Home) _____ (Mobile) _____
*Email: _____

Product Information

*Model _____ *Serial Number _____ *Purchase Date DD/MM/YYYY

Note: 1 warranty card is applicable for only 1 product
When service is required, please call our service centre & provide the following information:
*Full Name *Address *Warranty Card No *Model & Serial No
Please produce this card, together with original purchase receipt upon servicing

Dealer's Information



Dealer's Stamp

**Warranty Period with effect from 1st March 2013

Dehumidifier/Iontizer	1 year (Except for Replaceable Filters)	Air Purifier with Smart Inverter Motor	1 year, 10 years on Smart Inverter Motor
-----------------------	--	--	--

** Warranty coverage applies to brand new unit with proof of purchase invoice which is inclusion of display unit sold at dealer outlets.
***With effect from July 2012, there will be no warranty extended for refurbished unit with bore a "REFURBISH" mark at the back of the product.
**** This warranty is valid only in respect of LG products purchased locally (in Singapore) & through authorized dealers agents with supporting document (i.e. proof of purchase), otherwise the warranty is considered invalid.

OWNER'S RESPONSIBILITY

Please note that you will have to pay for attendance and correction of the under mentioned problems although the set is under warranty:

- 1 POWER - No power because power plug is not pushed in or power is not switched on or no power at points (check by using another appliance)
- 2 USER'S CONTROL - Not set according to Owner's Instruction Manual
- 3 REMOTE CONTROL - Not set according to Owner's Instruction Manual
- 4 RF signal or SCV setup box, customer is liable for the transportation charge \$50.

Please log on to www.lg.com for a list of self help answers for simple troubleshooting.

TERMS & CONDITIONS OF WARRANTY

- 1 The appliance is warranted for periods as specified respectively above in respect of service and manufacturing faults and defective materials and parts from the date of registered purchase, and LG Electronics (S) Pte Ltd guarantees the following:
 - 1.1 The sales receipt or purchase invoice showing the date of purchase of the Product, showing the serial number and date of purchase by showing the date of purchase. Customers may be asked to furnish proof of ownership and date of purchase by showing the sales receipt/purchase invoice. This warranty extends only to the original purchaser, and is non-transferable to anyone who subsequently purchases, leases or otherwise obtains the product from the original purchaser.
 - 1.1.1 Servicing will provide free of charge for the period specified above from the date of purchase.
 - 1.1.2 The warranty does not cover damage caused by accident, misuse, neglect, or other circumstances.
 - 1.1.3 The warranty does not cover demonstration / installation of the product/purchase.
 - 1.1.4 Transportation, delivery and handling charges incurred in the transport of the Product to and from LG or its authorized service centre will be borne by the Consumer.
- 2 Defective parts will be replaced free of charge if the defect is reported within the specified period from date of registered purchase with the exception that:
 - 2.1 Defective inverter linear compressor for refrigerator or freezer will be replaced free of charge if defects are reported within the specified period from date of purchase. However, labour charges, cost of spare parts, and call & other related components, if applicable, shall be borne by the purchaser; if the defect is reported after the expiration of the 2nd year warranty period for labour as stated above.
 - 2.2 Defective bells, bulbs/lamps and rubber gaskets will be replaced free of charge only if defect is reported within 6 months from date of registered purchase.
 - 2.3 Defective (wear & tear) door gasket for drum type washing machine will be replaced free of charge if defects is reported within 5 years from date of registered purchase.
 - 2.4 Defective motor for Direct Drive washers will be replaced free of charge if defect is reported within 10 years from date of registered purchase. Labour charges, however, be borne by the purchaser.
- 2.1 Notwithstanding anything contained herein, LG Electronics (S) Pte Ltd shall not be responsible or liable for any of the following:
 - 2.1.1 Acts of God or any person or persons intentional or otherwise, including but not limited to fire, flood, lightning, theft, war, riot, strike, sabotage, pest, or any act of God.
 - 2.2 Regular maintenance (i.e. cleaning) of washing machine tub.
 - 2.3 Defects or fault in Home Appliances which have been used for commercial purposes or which have been rented/leased or which have been otherwise subject to other than household use.
 - 2.4 Damaged or missing parts which are reported more than one week from the date registered purchase.
 - 2.5 Damage/ malfunction to accessories including but not limited to remote control units, antennas, LCD or battery covers, casing, and other accessories.
 - 2.6 Damage or malfunction caused by improper or incorrect installation, poor or inadequate maintenance, or use or operation of the appliance otherwise than in accordance with the manufacturers' instructions, for example, subjecting the appliance to excessive electrical voltage.
 - 2.7 Home servicing of portable appliances.
 - 2.8 Normal wear and tear, corrosion, rust, stains, scratches, dents on the body or casing or paintwork of the appliance.
 - 2.9 Damage to property including but not limited to video cassettes, compact discs, etc. arising from or in connection with the use of the appliance or any malfunction or defect in the appliance.

• Warranty Terms and Conditions apply.

** Wear & tear refers to condition beyond repairs and not cosmetic appearances, for example stain, mark.

- 2.10 The cost of providing access to any appliance by whatever means necessary for purpose of carrying out repairs or servicing in the event that the location or position at which the appliance is installed is such that there is no reasonable access to the appliance for such repairs or servicing to be carried out.
- 2.11 Any damage to property caused in the process of carrying out repair or servicing of appliance which are installed in positions or locations which make it difficult or unreasonable for such damage to be avoided.
- 2.12 Damage caused during transit where appliance is transported for the purpose of servicing or repair, or in relation thereof or in connection therewith.
- 2.13 Damage or loss due to additional rental charges for video cassettes, VCDs, DVDs, etc. consequential upon any malfunction, defect or damage in the appliance.
- 2.14 Damages for loss of use due to any malfunction, defect, damage or breakdown of the appliance.
- 2.15 For TV/ Display panel (E.g. Plasma/ LCD/ LED TV, etc) up to 5 non-active pixels may appear on the screen as a fixed point of blue, green or red.
 - 2.16 This does not affect the performance of the product(s) or does not constitute as a product defect.
 - 2.17 This does not include panel cracks, burn marks on TV and display screen.
 - 2.18 For LCD/LED Monitor, up to 2 non-active pixels or pixels as a fixed point of blue, green or red.
- 2.17 This does not affect the performance of the product(s) or does not constitute as a product defect.
- 2.18 Cracking sounds - This sound generated by the expansion / contraction of the front panel, back covers etc due to the changes of temperature.
- 2.19 LG strongly recommends that separate permanent written records be kept of all important data. Data may be lost or altered in virtually any electronic memory product under certain circumstances. Therefore, LG assumes no responsibility for data lost, destroyed or altered as a result of improper use, repairs, defects, battery replacement, use after the specified battery life has expired, or any other cause.
- 2.20 All the rights of the warranty will be void and null if serial number has been altered, effaced or removed.
- 3 This warranty shall exclude request pertaining to all refund, replacement or exchange.
- 4 LG hereby expressly provided that any liability of LG Electronics (S) Pte Ltd for any loss or damage whatsoever arising from, resulting with the use of the product, shall be limited to the extent of the purchase price (excluding installation costs) of the appliance. Similarly, LG Electronics (S) Pte Ltd's liability for any breach of this guarantee shall be limited to the purchase price (excluding installation costs) of the appliance.
- 5 This guarantee is valid only in the mainland of the Republic of Singapore.
- 6 This guarantee shall not apply in respect of any appliance which has been tampered with, or which has undergone repair, adjustment or servicing by persons other than those authorised by LG Electronics (S) Pte Ltd to do so.
- 7 Replacement Units and Repair Parts may be new or factory remanufactured.
- 8 The terms of this guarantee shall not be varied except with the written and express consent or agreement of LG Electronics (S) Pte Ltd.
- 9 While LG Electronics (S) Pte Ltd endeavours to repair any defect after the warranty period, it is subject to availability of parts from the manufacturers.

Please
Affix
Stamp
Here

LG Electronics (S) Pte Ltd

Service Centre
No: 991D, Alexandra Road
#01-14
Singapore 119972

MEMO



用戶手冊

空氣清新機

為了安全輕鬆地使用本產品，請於使用前細閱手冊。

請妥善保管隨附的保用證。

本電器為僅供在家使用的室內家用電器。

請勿將此電器用於商業、試驗或工業用途。

型號：AeroFurniture

HK 廣東語

www.lg.com

Copyright © 2023 LG Electronics Inc. All Rights Reserved.

目錄

安全須知

04 閱讀並保留這些說明

04 安全標誌和指示

04 警告

05 操作電源插頭或電源線

06 安裝產品

07 使用產品

08 使用 UVnano 功能

08 注意

08 安裝產品

09 使用產品

09 廢置產品

使用 LG ThinQ

10 LG ThinQ 應用程式

10 安裝應用程式 (APP) 和註冊產品

10 使用 **LG ThinQ** 應用程式前

11 升級產品應用程式

11 開放來源程式碼軟件

須知

12 詳看產品外觀

12 正視圖

13 桌子

14 濾網

15 其餘配件

16 組裝及準備

16 組裝產品

17 卸下濾網的保護塑膠袋

18 選定安裝場所

18 移動產品

19 更換桌子和桌子頂部

開始使用

21 查看控制面板

21 控制空氣清新機

22 操作空氣清新機

22 操作前須知

22 待機開/關

22 調節速度

23 使用附加功能

23 設定氣氛燈亮度

23 使用 UVnano 功能

24 智能裝置充電

25 整體空氣品質

25 了解整體空氣品質

保養

26 產品的保養與清潔

26 清潔外觀

27 清潔PM1.0感應器

28 清潔和更換濾網的週期

28 狀態面板提示

29 清潔濾網

29 更換濾網

29 重置濾網更換提醒

30 存放

30 存放產品

本手冊內的圖片及內容或與您所購買的型號有所不同。

本手冊可能被製造商修訂。

故障報告前確認事項

- 31** 診斷故障
 - 31 利用 **LG ThinQ** 診斷故障原因
- 32** 故障排除
 - 32 在調用服務前
 - 32 運轉
 - 33 狀態面板
 - 33 異味
 - 34 LG ThinQ
- 35** 產品規格
 - 35 規格指南
- 36** 產品保用證

安全須知

閱讀並保留這些說明

下述安全準則旨在防止因不安全或不正確操作設備而造成不可預見的風險或損害。
指南分為「警告」與「注意」，分述如下。

安全標誌和指示



顯示的該標誌表示可能造成風險的情況和操作。
仔細閱讀標有該標誌的文本，並遵循指示以避免風險。



警告

如若不遵循該標誌指示則可能會導致重傷或死亡。



注意

如若不遵循該標誌指示則可能會導致輕微受傷或產品損壞。

為一般使用者而設的機器。

警告



警告

為了降低爆炸、火災、死亡、觸電、受傷或人員燙傷等危險，在使用本產品時，請遵循包括以下的基本安全預防措施：

家中的兒童

- 除非有負責其人身安全人員對其使用本設備進行適當的監督或指導，本設備不適用於身體、感官或精神受損的人員，或缺乏經驗或知識的人群（如兒童）。請看管好兒童以免視本設備為玩具。


操作電源插頭或電源線

⊘ 禁止事項

- 請勿用濕手接觸電源插頭。



- 請勿破壞電源插頭和電源線。請勿破壞或任意延長電源線，避免放置靠近高溫處，也勿過度彎曲電源電纜或在電源線上放置重物，和扭扯、綑綁電源線。
- 請勿將電源插頭連接到無接地線的多孔插座(附著型)、插頭轉接器或其他配件。
- 請勿將電源插頭壓在產品背面或倒插。



- 請在清潔產品或更換濾網時拔下電源插頭。
- 請勿連續插入、拔出電源插頭。
- 請勿將運轉中的電源線插頭拔除。

○ 遵守事項

- 本產品適用電壓為 220-240 V。請務必將電源插頭連接到有接地插頭的 220-240 V 專用插座上。
- 若欲使用多孔插座，請使用具有電流量 20 A 以上接地插頭的多孔插座(拖板)。請在多孔插座上只使用本產品一個裝置。
- 安裝新產品時，請盡可能使用新購買的多功能插座，定期檢查電線外部絕緣包覆及插頭連接狀態。
- 請先擦乾淨插頭上的濕氣或灰塵後，將插頭牢固插入插座。
- 拔出電源線時請務必抓住電源插頭，勿拉扯電源線。
- 若遇到行雷、閃電或長時間不使用本產品，請拔掉電源插頭。
- 請注意勿讓寵物啃咬電源線。
- 若產品內部的電器零件受水浸，請拔除電源線並連絡 LG Electronics 客戶諮詢中心。
- 若電源線或電源插頭損壞，亦或電源插座的孔口變鬆時，請停止使用並連絡 LG Electronics 客戶諮詢中心。


安裝產品

禁止事項

- 請勿在下列地方置放產品。
 - 請勿在潮濕的地方安裝本產品並遠離水或飛濺的雨滴
 - 請勿在粉塵多或溫差變化嚴重的地方(室外、溫室)安裝本產品
 - 請勿在可燃氣體可能外洩或有工業用油或金屬顆粒之處安裝本產品
 - 請勿將產品安放在不平或傾斜的平面
 - 請勿將產品置放於墊子或棉被上
 - 請勿在暴露於直射陽光或靠近生熱設備之處安裝本產品
- 只有 LG Electronics 客戶諮詢中心的授權修理人員才可拆解、修理和修改本產品。
- 請勿讓產品和電源線接觸高溫表面。

遵守事項

- 請將本產品的電源插頭安裝於容易插拔的位置。
- 請安裝後，馬上丟棄產品的包裝材料（塑膠袋、發泡膠材料等）。
兒童在玩耍時可能會被包裝引致窒息。



- 為了降低火災的風險，請將本產品的排氣口置放於遠離紡織物、窗簾或可燃性材料至少 1m 的距離。

使用產品

⊘ 禁止事項

- 請勿使用金屬製和粗糙的刷子、抹布或海綿清潔產品。
- 只有 LG Electronics 服務中心的授權修理人員才可以拆解、修理或修改本產品。
- 請勿在電器附近使用或存放像是煙火、易燃物質（乙醚、苯、酒精、化學品、液化石油氣、可燃噴霧劑、殺蟲劑、空氣清新劑、化妝品等）或易燃物質（蠟燭、電燈等）。
- 請勿使用地墊、長條地毯或類似的覆蓋物遮蓋電源線。
- 請勿移動運轉中的產品。
- 請勿將手、金屬物體（棒子、髮夾）或異物放入進氣或排氣口。
- 請勿撞擊產品。
- 請勿安裝和使用破損零件。
- 請勿將可燃物置入產品內部。
- 請勿在蓋子開啟時操作產品。
- 請勿插電的狀態下清潔產品。
- 若智能裝置偏離無線充電座的中央，可能會導致過熱。

○ 遵守事項

- 如若設備不慎浸入水中，請停止使用並聯繫 LG Electronics 客戶諮詢中心。
- 若有漏氣（異丁烷、丙烷與 LNG 等）現象，請勿接觸本產品 或電源插頭，並立即讓該區域通風。
- 如果您發現任何異常噪音、異味或煙霧，立即拔下產品插頭並聯絡 LG Electronics 客戶諮詢中心。
- 請勿讓動物或寵物啃咬電源線。
- 請勿讓兒童攀爬或玩弄本設備。
- 當分解和重新安裝產品零件時，請小心勿讓身體的任何部位被產品夾住。

使用 UVnano 功能

此內容僅適用於具有 UVnano 功能的型號。

本產品是具有 UVnano 功能的型號，產品內部配有 UV-C 燈 (UV LED)。

禁止事項

- 請注意有可能因產品使用不當或產品損壞導致 UV-C 擴散至外部。即使暴露於少量的 UV-C 下也會對眼睛和皮膚造成傷害。
- 請勿在產品外部開啟 UV LED 功能。
- 當啟動 UVnano 功能時，請勿觸摸或清潔產品。
- 請勿任意拆下產品內部任何貼有紫外線危險標籤的配件。UV LED 可能會釋放出 UV-C。
- UV LED 是不需要清潔的配件，請勿單獨清潔 UV LED 或任何貼有紫外線危險標籤的配件。
- 使用者無法自行更換 UV LED 配件。請勿自行更換。
- 若 UV LED 損壞時，請勿啟動該功能。

遵守事項

- 請拔下電源插頭或關掉主電源開關後，才進行安裝、檢查、修理或更換 UV LED。
- 安裝、檢查、維修或更換 UV LED 時，必須使用 LG 客戶服務中心提供的 UVnano 模組，請聯絡 LG Electronics 客戶諮詢中心。
- 若 UV LED 損壞或需要更換時，請立即馬上停止使用並聯絡 LG Electronics 客戶諮詢中心。

注意

⚠ 注意

- 如果不遵循下列指示，或會導致產品損壞或造成輕微的傷害。

安裝產品

禁止事項

- 請勿將產品安裝在不穩定場所或劇烈震動的空間。
- 請勿將產品安裝在用戶視線水平之上。
- 請勿在車輛(露營車)上、船或飛機等內部安裝產品。
- 請勿移動過程中傾斜或推拉產品。
- 請勿在靠近電視或立體音響設備處置放產品。
- 請勿在有爆炸性危險的地方安裝或使用本產品。

遵守事項

- 請將產品安裝在地面穩固且平坦的地方。
- 請將產品安裝在沒有障礙物的空間。
- 當您在組裝桌子或是桌子頂部時，請勿讓其他物品卡在其中間。

使用產品

⊘ 禁止事項

- 請勿長時間在無穩定電壓處使用產品。
- 請勿為了祛除有毒氣體和一氧化碳時使用本產品。
- 請勿為了通風使用本產品。
- 請勿在進氣或排氣口附近放置障礙物。
- 請勿在靠近窗簾旁置放產品。
- 請勿為了特殊目的如保護動植物、精密儀器和藝術品等使用本產品。
- 請勿攀爬或坐在產品上。
- 請勿用濕手操作產品。
- 請勿在側放產品時使用。
- 請勿倚靠在產品上。
- 請勿把濾網使用在其他用途上。
- 若產品沾上肥皂水、化妝品、化學藥品、芳香劑或殺菌清潔劑時，請用濕紙巾或軟布擦拭產品。
- 請勿使用溶劑類型強力清潔劑。
- 請勿將具磁性或金屬物品放在產品的無線充電座上。
- 請勿將熱的物品放在產品上。
- 請勿將重物放在產品上。（建議重量：2kg 以下）

○ 遵守事項

- 人或動物皆請勿攀爬（特別是孩童），或放置物體在產品上（特別是磁鐵或金屬物品）。
- 請勿使用金屬製和粗糙的刷子、抹布或海綿，而是用超細纖維的軟布進行清潔。
- 請勿讓加濕器的水氣直接碰觸產品。

廢置產品

○ 遵守事項

- 棄置處理包裝材料（塑膠、聚苯乙烯等），勿讓兒童接觸。

使用 LG ThinQ

LG ThinQ 應用程式


安裝應用程式 (APP) 和註冊產品

若您安裝 **LG ThinQ** 應用程式，您可以隨時隨地方便管理您的 LG 家電。


使用 LG ThinQ 應用程式前

本功能僅適用於備有 Wi-Fi 功能的型號。


- 1 關閉智能手機上的流動數據功能。
 - Android 手機用戶請關閉流動數據功能。
 - iOS 手機用戶請關閉流動服務功能。



- 2 將智能手機連線到家庭用無線 Wi-Fi。
 - 您不能選擇字母包含 **5G** 的 Wi-Fi 名稱。本產品不支援使用 **5 GHz**。



- 3 請搜索下載與安裝 **LG ThinQ** 應用程式 (APP)
 - Android 手機用戶請在 Google play 商店搜尋 **LG ThinQ** 應用程式，下載與安裝。
 - iOS 手機用戶請在 Apple App Store 商店搜尋 **LG ThinQ** 應用程式，下載與安裝。



- 4 請打開已安裝的 **LG ThinQ** 應用程式並登入使用。
 - 您可以使用您正在使用的帳號登入或重新建立新的 LG 帳號登入。



- 5 新增裝置登入(+).

請在選擇產品的畫面上點選 **QR 註冊** 按鈕或直接選擇點選空氣清淨機。

 - 請依照 **LG ThinQ** 應用程式提供的產品註冊流程依序進行。
 - 如果您按下 **QR 註冊** 按鈕，附加訊息資料欄就會自動輸入該型號的名稱和序號。(請確認產品上二維碼。)

備註

- Wi-Fi 名稱和密碼在無線路由器上。
Wi-Fi 必須選擇 **2.4 GHz**。空氣清新機上安裝的 Wi-Fi 型號不支援 **5 GHz**，當選擇 **5 GHz** 時空氣清新機將無法連線到無線路由器。



- 建議使用 WPA2 類型的驗證及加密的無線路由器。
- 您的無線網絡連線品質可能會受到四周無線環境的影響。如果您的無線網絡連線遇上障礙，請聯絡您使用的網路公司服務中心。

- 當空氣清新機上的 Wi-Fi 裝置無法與無線路由器進行連線時，請嘗試以下方法解決。
 - 如果已啟用無線路由器的防火牆，請停用防火牆或新增例外條件。
 - *如果現有無線路由器的名稱或密碼包含特殊字符（★、□、■、♥等），空氣清新機將無法成功連接到無線路由器。
Wi-Fi 的無線網路名稱和密碼，請設定為英文字母或數字，或是英文字母和數字的組合。
 - *舊式的無線路由器不支援 Unicode UTF-8（是一種為了覆蓋全世界的所有字符，而設計出的標準處理字符的電子計算方式）。
- 如果空氣清新機與無線路由器的距離太遠，訊號強度會變弱。如果訊號強度變弱，可能需要耗費長時間才能註冊成功，或可能安裝失敗。
- 如果您變更無線路由器、網際網路服務供應商或密碼，請從 **LG ThinQ** 應用程式刪除已註冊的空氣清新機後，然後重新註冊電器。
- 本手冊的內容因 **LG ThinQ** 應用程式的版本而異，可能有所不同，並且可能會更改，恕不另行通知用戶。

升級產品應用程式

- 若有新的功能可以升級時，當該產品開啟電源後，狀態顯示面板上的 **UP** 顯示燈會亮起。
 - 在 **LG ThinQ** 應用程式選單上按下 **Feature Updates** 您可以進行軟體更新升級。
 - 在 **LG ThinQ** 應用程式程序中註冊產品後即可使用此功能。

開放來源程式碼軟件

欲獲得 GPL、LGPL、MPL 及其他有義務公開包含本產品內容原始程式授權的源代碼，及存取所有提及授權條款、版權聲明及其他相關文件，請瀏覽 <https://opensource.lge.com>。


LG Electronics 也可應您要求，在由您支付相關費用（如媒體成本、運費及處理費）的條件下以 CD-ROM 方式提供開放原始程式碼，如有需要請寄送電子郵件至 opensource@lge.com。

該產品最後一次出貨的三年內，任何收到此資訊的人可享此優惠。

須知


詳看產品外觀

正視圖



- ① **狀態面板**
 - 顯示面板可確認產品設定和空氣狀態。
- ② **無線充電座**
 - 為具有無線充電功能的智能裝置充電。
- ③ **桌子頂部**
 - 本產品的桌子可分離和更換。
- ④ **UVnano LED (僅限個別型號)**
 - 清除空氣清新機內部風扇上的有害細菌。
- ⑤ **濾網**
 - 儘量減少過敏原、細顆粒物、可能的病態建築綜合症來源、煙霧和其他異味。
- ⑥ **感應器**
 - PM1.0 感應器：檢測粉塵濃度水平。
- ⑦ **Smart Diagnosis(智能診斷)**
 - 當本產品出現故障時，可使用**Smart Diagnosis(智能診斷)** 功能對本產品狀態進行檢查。
- ⑧ **進氣口 (蓋)**
 - 空氣透過進氣口進入空氣清新機。
 - 可分別卸下前後蓋。
- ⑨ **排氣口**
 - 透過濾網將淨化空氣排出。

桌子




- ❶ 氣氛燈
 - 調節氣氛燈亮度。
- ❷ 桌子底座分離按鈕
 - 同時按下兩側按鈕，可把桌子分開。
- ❸ 控制面板
 - 使用該面板設定產品（待機開/關、速度、氣氛燈）功能。
- ❹ 桌子連接部位
 - 產品主機和桌子連接的部位。
- ❺ 固定/分離桌子頂部的裝置
 - 組裝桌子頂部後，可以固定/分離。

✓ 備註

- 桌子和桌子頂部（圓形/橢圓形）可在最近的客戶服務中心或進入網站（www.lg.com）。

濾網



❶ 除臭濾網

- 減少浴室、香煙、食物和其他常見來源的異味。

❷ Aero Series V 濾網

- 減少空氣中的 PM1.0 和煙味。

❸ 濾網手把

- 用來從產品上取下濾網或裝上。
- 請將有手把的一面朝上。

❹ 超細濾網

- 與過敏原收集維護網濾網的外部相連，主要可在第 1 階段消除沉浮在空氣中的大型顆粒，如大灰塵。

⚠ 注意

- 濾網一體成形，因此請勿強制將濾網分離。
- 請勿扔濾網或作為他用。

● 備註

- 剛購買的新濾網可能有氣味。使用產品超過一天後，氣味會自然消失，請安心使用。
- 濾網的清潔頻率和更換週期，會隨著濾網使用的環境和使用的時間而不同。
- 濾網更換周期最長為 1 年。室內空氣污染狀態越嚴重，濾網的壽命也會縮短。
- 如果室內有濃重氣味，請先進行室內通風，消除氣味（氣體），再使用空氣清淨機，消除殘餘氣味。
- 空氣清新機長期間未用後，突然再次使用產生氣味時，請將產品放置通風處，開啟速度階段，可降低濾網中的氣味。
- 當產品在潮濕或濾網吸入過多加濕機水分的環境下繼續使用時，您的濾網可能會發出氣味。若濾網因受潮而產生氣味，請將濾網放置在陽光下風乾後使用。
- 當超音波加濕器和空氣清新機兩者同時使用時，加濕機噴霧裡含有的石灰成分，會導致濾網使用壽命急速下降。
- 若您同時使用加濕機和空氣清新機，建議您使用氣化式加濕機。
- 一氧化碳 (CO) 的有害氣體，主要是由室外飄入，無法透過濾網消除。
- 使用產品時，請保持門窗緊閉。但是，如果長期間在密閉空間使用產品，二氧化碳濃度可能升高，請定期進行室內通風。
- 空氣清新機的除異味功能是將空氣中的氣味（氣體）捕捉到濾網上的方式。如果您在氣味濃重的室內長時間使用產品，濾網效能可能會大幅下降。若四周的氣味滲入濾網，啟動空氣清新機產生氣味時，表示已屆滿使用期限，您必須購買新的濾網更換。濾網是消耗品，即便在保固期內需更換濾網，也應付費購買。
- 濾網可在最近的服務中心或進入網站（www.lg.com）。

其餘配件



①


- ① 用戶手冊

組裝及準備


組裝產品

使用產品前，請卸下包裝產品的保護性塑膠袋和濾網的塑膠袋。

- 1 打開箱子取出產品的主體和桌子後，卸下塑膠袋。
- 2 請依照下圖示，準備好產品主體和桌子。
 - 有 **LG 標誌** 方向是產品的正面。
 - 直視桌子的正面時，以 **LG 標誌** 為基準，左邊是狀態面板，右邊是無線充電座。



- 3 安裝時，桌子對準好主體裝上。



⚠ 注意

- 把桌子組裝到產品主體時，要聽到發出「咔」的聲音。
 - 若組裝不當，產品將無法運作。
- 把桌子組裝到產品主體上時，請注意組裝的方向。
 - 這是產品失誤及故障的原因。
- 若只將產品主體單獨連接電源而未裝上桌子，將無法運作。


✔ 備註

- 組裝橢圓形時，請按照圓形的相同方式。


卸下濾網的保護塑膠袋

使用產品前，請卸下固定在濾網上的固定膠帶和保護性塑膠套。


- 1 以產品的正面為準，抓住進氣口（蓋）的兩側，並輕輕拉出取下。
 - 產品的中央有 **LG 標誌** 的方向是產品的正面。




- 2 請先卸下濾網再拆除保護性塑膠袋。
 - 當您要卸下濾網時，請抓住濾網上的保護性塑膠袋將其拉出。



- 3 請將濾網安裝回產品。
 - 請將濾網的手把面向上推入。



- 4 關閉蓋子前，請插入蓋子底部兩端的固定零件至產品底部的孔洞。





⚠ 注意

- 使用產品前，請務必卸下濾網的保護性塑膠袋。
- 安裝濾網時，請注意濾網的方向。
 - 這是產品失誤及故障的原因。
 - 濾網有手把的部分是上面。

選定安裝場所


- 請將產品安裝距離牆壁保留 1 米的距離。
 - 若進氣口無確保預留空間，淨化效能可能下降。



- 產品效能可能依據操作環境不同（如溫度和濕度）。
 - 達到最佳效能，建議在 40% ~ 70% 的濕度時使用。
- 請勿暴露於直射光線或鄰近強光照明燈具之處安裝本產品。
 - 這可能是導致產品變色的原因。

移動產品

- 移動或存放產品時，請將電源線環繞產品底部，避免於地板上拖行。
 - 這可能是導致電源插頭毀損或刮傷地板的原因。
- 搬運產品移動
 - 請在搬運產品時握住產品桌子的兩側下端，安全移動。



⚠ 注意


- 請在搬運產品之前先確認桌子是否有固定好。
- 請勿在搬運產品時握住外蓋子。蓋子或會意外打開，導致產品掉落。
- 當抓住桌子下緣位置時，請勿按壓**桌子底座分離**按鈕。桌子與產品主體分離時，桌子可能會掉落。
 - 產品掉落時，可能會造成傷害或導致產品故障。

更換桌子和桌子頂部

更換桌子

使用產品前，請卸下桌子的保護性塑膠袋。

- 1 請同時按壓桌子下端兩側的**桌子底座分離按鈕**，向上拉進行分離。



- 2 請將新的桌子組裝到產品主體。
• 請參閱組裝產品指南。


⚠ 注意

- 進行組裝或分離桌子時，請避免讓水滴或異物進入桌子連接部位。
- 當產品處於運轉狀態時，請勿分離桌子。
- 請在更換桌子時，才使用**桌子底座分離按鈕**。
- 按鈕使用不當可能會導致受傷或產品故障。


更換桌子頂部

使用產品前，請卸下包覆著桌子頂部的保護性塑膠袋。

- 1 在桌子分離的狀態下，桌子兩側有桌子頂部的**固定/分離桌子頂部**的裝置，請依照下列圖示進行解鎖。




- 2 如下圖示，請先拆解無線無線充電座所在位置的連結部分，再把桌子頂部套向上提起將其分離。




✓ 備註

- 請拆解圓形的 6 個連結部分、橢圓形的 10 個連結部分。



- 橢圓形也方法一致，請先拆解無線充電座所在位置的連結部分，再把桌子頂部向上提起將其分離。

- 3 請將新桌子頂部放置在無線充電座的位置後裝入連結部分，將桌子頂部**固定/分離桌子頂部**的裝置依照下列圖示進行固定。



✓ 備註

- 適用購買額外配件。
- 固定桌子頂部時，請關上固定裝置直至發出「咔」的聲音。

⚠ 注意


- 當您在組裝及分離桌子時，請注意避免夾到手指或指甲。
 - 有受傷的風險。
- 當您在分離桌子，請注意避免碰撞到身體部位（臉部、胸部等）。
- 請您在更換桌子頂部時，才使用桌面的**固定/分離桌子頂部**的裝置。
 - 設備使用不當可能會導致人身傷害或產品故障。

開始使用

查看控制面板

控制空氣清新機

狀態面板（桌子正面）



1 附加功能指示

圖示 (Icon)	說明
	Wi-Fi 連線後，會顯示連線成功，即可進行遙控操作。
	有新增功能時會顯示燈號。

2 空氣質量指示燈


- 根據PM10/PM2.5/PM1.0的粉塵濃度，將空氣質量的狀態用顏色（綠，黃，橙，紅）表示。
- 設定睡眠模式時，淨化指示燈號將關閉。

3 速度指示燈

- 指示在自動、弱、中、強和睡眠之間設置的風速。

速度	顯示	說明
自動		3 個 LED 循環
弱		1 個 LED 亮起
中		2 個 LED 亮起
強		3 個 LED 亮起
睡眠		1 個 LED 亮起 ('弱' 亮度的 50%)

控制面板（桌子底部）



1 待機開/關按鈕

- 您可以打開或關閉電器的電源。

2 速度按鈕

- 設定風速。

3 氣氛燈按鈕

- 調節氣氛燈亮度。

備註


- 按住控制面板上的按鈕 3 秒，即可使用附加功能。

按住 3 秒鐘	附加功能
	Wi-Fi 連線（遠端操作）
	Smart Diagnosis(智能診斷)
	停用濾網更換提醒

操作空氣清新機

操作前須知


※ 控制面板於桌子底部（下面/背面）。



待機開/關

您可開關產品的電源。

- 待機開/關按鈕開始運轉




備註

- 如果您停止後並恢復操作，將以您上次選擇的運轉模式開始淨化空氣。
- 當產品運轉中拔掉插頭或停電時，它會記住最近一次使用的模式（速度、照明）。

調節速度

可讓您調節空氣清新機的風速。

- 當產品在運轉的狀態，您每按一次**速度**按鈕，就會依序自動 (Auto) → 弱 → 中 → 強 → 睡眠的模式進行反復更換。




備註

- 速度越強時，清潔空間的速度也會加快。
- 如果設定為自動 (Auto)，會根據室內空氣的污染程度（粉塵濃度）自動調節速度。
- 設定睡眠模式時，空氣質量指示燈號將關閉。

使用附加功能

設定氣氛燈亮度

調節氣氛燈亮度。



- 當產品在運轉的狀態下，每按一次**氣氛燈**按鈕，桌子底座的下方燈光亮度，就會依序**亮起** → **中等亮度** → **熄燈**的順序進行更換。

備註

- 氣氛燈的初始設定是關閉的模式。
- 當風速是**睡眠**模式或停止運轉的狀態，您都可以調節氣氛燈亮度。

使用 UVnano 功能

※ 該內容僅限於具有 UVnano 功能的型號。
對空氣清新機內部的風扇進行殺菌，使空氣更加乾淨 開啟循環功能。

- 您可以使用 **LG ThinQ** 應用程式，更改 UVnano 的設定。
- 當您第一次使用本產品時，就設定好有 UVnano 的功能。

備註


- UVnano 是減少有害細菌的 UV（紫外線）LED 和紫外線波長單位奈米的複合詞。
- UV LED 是不需要清潔的配件，請勿單獨清潔 UV LED 或任何貼有紫外線危險標籤的配件。
- 若 UV LED 損壞時，請勿啟動該功能。
- 當您在清潔產品或更換濾網，請拔下電源插頭。

注意


- 本設備包含 UV-C 發射器。
- 以非此產品設計目的方式使用或損壞外殼可能會導致危險的 UV-C 輻射洩漏。
- 即使劑量很小，UV-C 輻射也可能對眼睛和皮膚造成傷害。
- 切勿使用明顯損壞的器具。
- 用戶切勿自行更換 UV-C 發射器。

智能裝置充電

- 在產品連接電源線的狀態，將一台支援無線充電的智能裝置放在充電座上，即可開始充電。



- 請將您的智能裝置放在無線充電座的中央。
 - 若智能裝置脫離了無線充電座的中央，可能無法正常充電。
 - 智能裝置離中心越遠，充電效率就越低，可能會反覆出現暫時中斷充電的現象。



⚠ 注意

- 無線充電座和智能電子裝置之間若有硬幣或其他金屬性物質時，請移除後使用。
 - 金屬物質可能會中斷無線充電。
 - 金屬物質在充電的過程中可能發熱，造成低溫灼傷。

✔ 備註

- 每個智能裝置的無線充電特性都不同，請確認智能機器的產品說明書中的無線充電相關內容後使用。
- 充電過程中，無線充電座溫度高，會中斷充電。
 - 為了保護智能裝置，充電會在特定溫度以上時停止，充電功能在下降到一定溫度時重新啟動。
- 智能裝置的保護套可能導致無法充電。
 - 金屬材料及環扣支架可能導致無法充電。
 - 保護殼厚度的關係，充電可能會被延遲或中斷。
 - 當您使用錢包/卡片式保護套時，信用卡與保護套厚度，可能會阻礙延遲或中斷充電。
- 如果將信用卡等磁性物質放置在無線充電座或充電座附近，磁卡可能會受損。
- 如果將智能裝置放在充電座，充電將在 3~5 秒開始。
 - 充電時間可能因智能設備製造商不同而異。
 - 如果 3 到 5 秒後仍未充電，請拿起智能裝置並嘗試更換位置。
- 如果在網絡信號強度較弱的區域使用無線充電，智能型手機的網絡性能可能會下降。
- 如果將有線充電器連接到正在無線充電的智能裝置，則無法使用無線充電功能。

整體空氣品質

了解整體空氣品質

整體空氣品質以粉塵濃度為標準，根據室內空氣的污染程度分別標示為綠、黃、橙、紅 4 個等級。

顏色	整體空氣品質	顆粒物濃度 ($\mu\text{g}/\text{m}^3$)		
	狀態	PM10	PM2.5	PM1.0
紅色	較差	255 或以上	56 或以上	56 或以上
橙色	不健康	155 ~ 254	36 ~ 55	36 ~ 55
黃色	中等	55 ~ 154	13 ~ 35	13 ~ 35
綠色	良好	54 或以下	12 或以下	12 或以下

- 顆粒物濃度可以通過空氣質量指示燈的顏色來識別。
- 整體空氣品質顯示的顏色根據最差粉塵濃度濃度之條件確定。

備註


- 本公司產品的粉塵濃度階段是以光學方式測定粉塵個數，換算成微細塵埃濃度後標示的結果。
- 與其他儀器和其他產品所採用的計量標準相比，本產品上顯示的顆粒物濃度或會有所不同。
- 超微細塵埃的粉塵濃度等級適用與極微細塵埃相同的標準。（LG 公司的標準）
- 當不同或同一產品在同一空間內使用時，空氣流通可能會導致粉塵濃度等級的差異。
- 粉塵感應器周圍的空氣流動可能干擾了粉塵感應器的偵測，導致顯示的粉塵濃度等級和實際粉塵濃度不同。
- 如果產品在以下環境中使用，顯示的粉塵濃度等級可能與實際不同。
 - 布沙發和床周圍、多毛地毯周圍、整理毯子/衣服、使用吸塵器、有蟲和寵物的地方、濕度高的地方
 - 像是建築工地、馬路邊、工廠、出入口、窗戶、通風口周圍等，是外部空氣可進入之處
 - 使用的物品會產生蒸汽和微顆粒（像加濕器、烹調、噴霧劑等）的地方
 - 即便拍打棉被和打掃等動作會產生灰塵，甚至灰塵大於微細塵埃，但粉塵感應器也有可能不會偵測反應，但大灰塵會被過濾器掉。

保養

產品的保養與清潔

清潔外觀

- 1 請使用吸塵器吸除進氣口（蓋）的粉塵。
- 2 再以軟布拭擦桌子頂部外部。



備註

- 清潔桌子頂部時請參考以下內容。
 - 如果有灰塵或污漬，請用乾淨的超細纖維布或清潔用濕紙巾擦拭。
 - 如果您沾有化妝品的手觸摸桌面產生污漬，請將超細纖維布沾上洗面乳(卸妝乳)將其擦拭乾淨。

⚠ 注意


- 請勿使用鹼性洗滌劑擦拭產品。
- 請勿使用硫酸、鹽酸或有機溶劑（如稀釋劑、煤油、丙酮等）清潔產品，或不要把貼紙貼在產品上。產品表面或會毀損。
- 請注意避免讓水進入產品內部。
- 沾上肥皂水、化學藥品、芳香劑、殺菌清洗劑等時，請立即用軟布或濕紙巾擦拭。
- 請勿讓鑰匙或刀具等鋒利部分直接接觸產品表面。
 - 產品表面或會毀損。
- 請勿將圓珠筆、蠟筆、彩色鉛筆等物品，直接接觸產品表面。
 - 產品的表面可能有污漬或是毀損。

清潔PM1.0感應器


PM1.0（極微細塵埃）感應器可偵測粉塵和大顆粒粉塵的污染度。因此，建議您需每 2 個月定期清潔鏡頭。

- 1 以產品的正面為基準，抓住進氣口（蓋）的兩側，並輕輕拉出取下。


- 產品中央有 **LG 標誌** 是產品的正面。




- 2 請把感應器蓋子往上推。



- 3 請用棉花棒沾取少量水擦拭鏡頭後，再用乾的棉花棒擦拭水分。




- 4 關閉感應器蓋子。



備註

- 請勿用水以外的物質擦拭感應器。
 - 這或會導致產品故障。
- 打開或關閉傳感器蓋子時，可能會因摩擦而產生聲音。

清潔和更換濾網的週期

種類	清潔週期	更換週期
 濾網	超細濾網 如果髒污，請使用吸塵器或軟刷，清潔超細濾網。	1 年

備註

- 清潔週期可能因產品的使用環境和使用時間而異。
- 如果您長時間未清潔產品，您可能會聞到異味且產品效能不佳。
- 濾網是消耗品，因此，即使在保養期內，在屆滿使用期限時，您必須購買新的濾網更換。濾網可在最近的服務中心或 LG 電子官網 (www.lg.com) 進行購買。
- 若四周的氣味滲入濾網，啟動空氣清新機產生氣味時，表示已屆滿使用期限，請您必須購買新的濾網更換。濾網是消耗品，即便在保養期內，在屆滿使用期限，您必須購買新的濾網更換。
- 雖然濾網的上下部使用紙代替塑料，但如果您反覆放入或取出濾網入，濾網的上下底部可能會出現刮痕。
- 即使濾網上下部出現刮痕，使用上是沒有問題的。

狀態面板提示


提示圖示 (提醒圖示)	說明	處理方法
	3 顆 LED 燈同時閃爍	需要更換濾網時會亮燈。

備註


- 考量產品運轉時間，出現濾網更換提醒。將根據操作時數和環境決定更換濾網頻率。

清潔濾網

- 1 請卸下產品的正面蓋子和背面蓋子。
 - 以電器正面的 **LG 標誌** 為準，抓住進氣口（蓋）的兩側，並輕輕拉出取下。



- 2 請使用吸塵器或軟刷，清潔包覆罩在 Aero Series V 濾網外的極細濾網上的粉塵。




⚠ 注意

- 請勿用水洗除臭濾網和 Aero Series V 濾網。此舉可能縮短濾網的使用壽命。
- 使用吸塵器，請小心注意不要損害極細濾網。
- 若濾網沾上液體，請小心注意不要損害濾網。

更換濾網

請卸下產品正蓋子和背蓋子，拉住手把取出並更換濾網。


- 為避免更換濾網時污染周遭環境，請在卸下濾網前，在地板上鋪設報紙。



重置濾網更換提醒

狀態面板的濾網更換提醒已停用並重置更換。

- 請同時按住控制面板的**待機開/關小氣氛燈**按鈕 3 秒鐘或更長時間。



✔ 備註


- 需要更換濾網時會顯示通知(提醒)。
- 更換新濾網時使用。

存放

存放產品

如果產品長時間不使用，請將其置放於陰涼乾燥之處。

- 1 天氣晴朗時，讓產品運轉 1 小時或更長時間。
 - 去除電器內部的濕氣，可以預防發霉。
- 2 關閉電源並從電源插座拔出電源線。
 - 將電源線環繞於產品底部。
- 3 包裝產品之後，把產品存放在陰涼處，避免灰塵或外來物質進入產品。



注意

- 請勿在潮濕或曝露於陽光直射之處存放產品。否則，產品可能變形、故障或產生異味。

故障報告前確認事項

診斷故障

利用 LG ThinQ 診斷故障原因

這是一種可以診斷產品故障原因的功能。

備註

- 服務中斷可能會因外部因素（無法連接 Wi-Fi、解除 Wi-Fi 連接、應用程式商店政策、應用程式不可用等）而停止，這並非 LG 電子的過失。
- 此功能可能會隨時修改，恕不另行通知，並且視您所在的位置而定，其功能可能有所不同。

利用 LG ThinQ 診斷故障


如果您配備 Wi-Fi 的電器發生問題可以透過 **LG ThinQ** 應用程式，將故障排除資料傳輸到智能手機。

- 啟動 **LG ThinQ** 應用程式，並在選單中選擇 **Smart Diagnosis(智能診斷)** 功能。
- 按照 **LG ThinQ** 應用程式中的說明進行操作。


使用 Audible Diagnosis 進行問題診斷

使用應用程式的**Smart Diagnosis(智能診斷)**持續失敗時，請在應用程式引導的按下“轉至「聽覺診斷」”的按鈕，然後按照出現的說明進行操作。

- 同時按住**速度**和**氣氛燈**按鈕 3 秒以上，執行 **Smart Diagnosis(智能診斷)** 功能。



- 將您的智能手機靠近電器。
 - 請將智能手機的麥克風朝向電器的正面。



- 資料傳輸完成之後，**Smart Diagnosis (智能診斷)**狀況會顯示在 **LG ThinQ** 應用程式中。

備註

- 為獲得最佳效果，請勿在傳輸聲調時移動手機。
- 請在安靜的環境下進行 **Smart Diagnosis (智能診斷)**。

故障排除

在調用服務前

在您聯絡客戶服務中心之前，請檢查以下各項。
如若存在故障，請聯絡當地客戶服務中心。

運轉

症狀	原因及解決方案
產品不運轉。	電源插頭是否未插在插座上？ • 正確插入插座。
	您使用的是 220-240 V 電壓嗎？ • 產品正規電壓是 220-240 V。請確認插座上標示的電壓。
	斷電了嗎？ • 請檢查家中的其他電器的電源。
	產品主體與桌子（檯面）是否組裝正確？ • 請參閱產品組裝指南，請正確組裝產品的主體和桌子。
風扇強度轉弱並發出噪音。	粉塵是否在超細濾網堆積？ • 適當清潔超細濾網。
	粉塵是否在濾網堆積？ • 更換濾網。
室內空氣未完全淨化。	室內空氣污染太嚴重嗎？ • 使用產品前，請進行室內通風。
	粉塵是否在超細濾網堆積？ • 適當清潔超細濾網。
	粉塵是否在濾網堆積？ • 更換濾網。
	是否在太寬廣或太空曠之處使用？ • 使用適合空間大小的產品。 • 避免在通風良好處，如出入口、門窗附近使用。
	周遭是否有障礙物？ • 移除障礙物。
	是否在角落安裝產品？ • 移動產品並再安裝一次。
無法無線充電。	您把智能裝置放在無線充電座中央了嗎？ • 當智能裝置偏離無線充電座的中央，則無法充電。
	智能裝置是否套有保護套呢？ • 保護套的厚度差異，充電可能延遲或中斷。 • 金屬材料的配件和環扣支架可能導致無法充電。 • 當您使用錢包/卡片式保護套時，信用卡與保護套厚度，可能會阻礙延遲或中斷充電。

狀態面板

症狀	原因及解決方案
空氣質量指示燈持續顯示紅色。	即使移至乾淨的室內顏色也不會改變？ <ul style="list-style-type: none"> 如果氣味量超出產品容忍度，顯示顏色不會改變。 從插座拔下電源插頭並在 1 分鐘後再次插上。
	您是否在產品周圍使用噴霧？ <ul style="list-style-type: none"> 請勿在產品周圍使用噴霧。

異味


症狀	原因及解決方案
排氣口和濾網傳出怪味。	您是否最近才購買產品？ <ul style="list-style-type: none"> 活性炭的氣味對人體無害。這與您在新車中聞到的氣味類似，首次使用一天或稍後便會消失。
	您是否在濃煙密慢和氣味濃重的地方使用它？ <ul style="list-style-type: none"> 當室內放有芳香劑、香薰、香薰，或是剛裝潢、更換壁紙，在該地方使用新濾網進行空氣清淨，濾網可能會滲出異味。室內通風，然後使用產品。
	濾網是否有異味？ <ul style="list-style-type: none"> 濾網更換週期會因使用環境而不同。若有異味，更換新濾網。
	是否處於烹調食物的環境？ <ul style="list-style-type: none"> 如果您烹煮或烤魚類/肉類時，長期間使用此產品，產品壽命將快速縮短。 烹調時儘可能開啟窗戶通風，並在通風後使用產品，消除氣味。
	環境潮濕嗎？ <ul style="list-style-type: none"> 潮濕的環境，濾網可能有異味。請將濾網放置在陽光下風乾後使用。

LG ThinQ

症狀	原因及解決方案
本產品無法透過 Wi-Fi 和智能手機連接。	連接到智能手機的 Wi-Fi 密碼是否不同？ <ul style="list-style-type: none">點擊智能手機的設定按鈕，然後在網絡列表中找到正在使用的 Wi-Fi。請長按按鈕，選擇[刪除網絡]，然後從頭開始重新進行新產品註冊。
	您的智能手機是使用流動數據，而不是 Wi-Fi 嗎？ <ul style="list-style-type: none">在智能手機的設置畫面上關閉流動數據功能後，打開 Wi-Fi 功能，然後註冊本產品。
	無線路由器的名稱（SSID）設置是否正確？ <ul style="list-style-type: none">無線網絡名稱（SSID）應為英文字母和數字的組合。（請勿使用特殊字元。）
	無線路由器的頻率不是 2.4 GHz 嗎？ <ul style="list-style-type: none">通過 Wi-Fi 連接產品時，電器僅支援 2.4 GHz Wi-Fi 網路。將無線路由器設置為 2.4 GHz，然後操作連線。若您要檢查無線路由器的頻率，請諮詢您的網際網絡電信公司或詢問路由器製造商。
	電器距離無線路由器太遠嗎？ <ul style="list-style-type: none">電器與無線路由器的距離太遠的情況，無線訊號會減弱，連線無法正常運作。請把無線路由器移到產品附近。

產品規格

規格指南



型號	AF20* 系列
電源	AC 220-240 V~ 50 Hz
外型尺寸 (① x ② x ③)	275 mm x 275 mm x 550 mm

※ 本產品沒有氣體感應器。

產品保用證

Service Commitment 服務承諾

LG's mission is to create value for customers. We are committed to improve the life of our customers by putting the customers first, and delivering the best possible pre and after sales services in the way they want.

為顧客創造價值乃LG一貫宗旨。我們致力提供最貼心的售前及售後服務，一切以顧客為先，希望為客戶帶來最優質的生活。



Warranty Card

產品保用證

Product Type 產品	Product Description 產品種類	Warranty Period (Year) 保養期 (年)
Refrigerator 雪櫃	Appliance 主機	3
	Inverter Linear Compressor* 線性變頻式壓縮機*	10
	Smart Inverter Compressor* 智能變頻式壓縮機*	10
Washing Machine 洗衣機	Appliance 主機	2
	Inverter Direct Drive Motor* 直驅式變頻摩打*	10
	Smart Inverter Motor* 智能變頻式摩打*	10
Dryer 乾衣機	Appliance 主機	2
	Inverter Motor* 變頻摩打*	10
	Dual Inverter Compressor* 雙迴轉變頻式壓縮機*	10
Vacuum Cleaner 吸塵機	Appliance 主機	2
	Inverter Motor* 變頻摩打*	10
	Battery* 電池*	1
Air Purifier 空氣清新機	Appliance 主機	2
	Inverter Motor* 變頻摩打*	10
Dehumidifier 抽濕機	Appliance 主機	2
	Dual Inverter Compressor* 雙迴轉變頻式壓縮機*	10
Styler 衣物護理機	Appliance 主機	2
	Smart Inverter Compressor* 智能變頻式壓縮機*	10

* This extended parts warranty is applicable on specific parts only. The consumer will be charged for labour after the product warranty has expired.

* 零件延長保養僅適用於產品上的指定零件，在產品的保養期後則需另付人工費用。

HK & Macau Area
香港澳門地區

Warranty Card 產品保用證

LG Customer Care Centre 客戶維修服務中心

Welcome to contact for detailed information 歡迎致電查詢詳細資料

Customer Service Hotline 客戶服務熱線 : (852) 3543 7777

LG Website 瀏覽網站 : www.lg.com

If you want to receive an additional 3 months warranty, please complete warranty registration within 1 month after purchase at

https://www.lg.com/hk_en/support/my-lg/product-registration

如欲享受額外3個月產品保養, 請在購買產品後1個月內登入

<https://www.lg.com/hk/support/my-lg/product-registration>

Privacy Statement

You are aware that any information supplied by you after purchase of our product will be retained by LG Electronics HK Ltd. and will not be released to third parties. You also authorize LG Electronics HK Ltd. to send you direct promotion materials. Please contact our Customer Service Hotline at (852) 3543 7777 if you wish to modify or erase your provided personal information.

私隱聲明

閣下在購買本公司產品後所提供的任何資料, 將會由LG Electronics HK Ltd.保有, 不會透露給予第三方, 並授權本公司對閣下發出直接推廣通訊。如希望修改或刪除所提供的個人資料, 可聯絡本公司客戶服務熱線(852) 3543 7777作出相關安排。

Thank you for your purchase of LG Electronics product under the terms and conditions listed on this warranty card.

多謝閣下購買及使用本公司之產品, 請參閱保用證所列之產品保用條款。

IMPORTANT : Please keep and present this warranty card and purchase invoice when services are rendered. Otherwise, this warranty will be voided.

重要事項 : 顧客請保留此保用證及購貨發票, 並需在檢查/維修時出示, 否則保用無效。

Refrigerator / Washing Machine / Dryer / Vacuum Cleaner / Air Purifier / Dehumidifier / Styler 雪櫃/洗衣機/乾衣機/吸塵機/空氣清新機/抽濕機/衣物護理機

- (1) The design of this product is not valid for commercial purpose.
- (2) Warranty is valid only for authorized product; parallel import and counterfeit product are invalid
- (3) Customer is expected to deliver and collect their products to and from the LGEHK Service Centre. This warranty is applied in vacuum cleaner and Ionizer (Model#: HPS-B090BW) only.
- (4) If check-up or repairing is required; customer must present the warranty card and original invoice. Upon any failure to present the above documentation, customer must pay for the cost of the services provided.
- (5) All parts replaced within the warranty period are the property of LGEHK. We have rights to handle those parts as necessary.
- (6) For vacuum cleaner, customer shall bear the cost of transportation to and from the service centre.
- (7) Warranty will be voided under the following conditions, and LGEHK reserves the right to refuse providing service and/or shall demand charges for any costs of servicing from customer
 - (a) Product has been modified or repaired outside of LGEHK Service Centre.
 - (b) Product has been mishandled, negligence such as leaving batteries unattended and thereby causing battery fluid leakage, applying the wrong voltage, forces of nature or accident.
 - (c) Installation maintenance of the product without following proper instruction from manufacturer.
 - (d) The model number of the item code attached has been erased or modified.
 - (e) The content of warranty policy has been modified without authorization
- (8) LGEHK is not responsible for any loss of data or system corruption during the process of transportation or repair to and from the Service Centre and due to the forces of nature.
- (9) LGEHK reserves the right to terminate or modify the terms of this warranty card without further notice. For exceptional cases, subject to report of our investigation, we reserve the right to terminate this warranty card or modify terms of warranty policy.
- (10) Our company will not be liable for any loss directly or indirectly caused by the breakdown of the product.
- (11) This warranty card is restricted within Hong Kong / Macao SAR only.
- (12) Transportation charges to outlying island shall be borne by customer.
- (13) LGEHK and its Authorized Service Centres reserve the right to use factory remanufactured parts or whole products for the same or functionally equivalent model when conducting product repairs and replacement.
- (14) In cases of any disputes, LGEHK have absolute and final discretion, and which be fully agreed upon and followed by all customers.
- (15) The Terms and Conditions shall be governed by the Law of Hong Kong. All disputes arising out of or in connection to the Terms and Conditions shall be resolved by Hong Kong Courts.

- (1) 此產品設計，不適用於商業用途。
- (2) 保修服務只適用於原裝行貨；水貨及冒牌貨均屬無效。
- (3) 客戶須自行將產品送往維修中心，並於修妥後自行取回。此條款只適用於吸塵機和離子機(型號:HPS-B090BW)。
- (4) 客戶要求維修服務時，必須出示保用證及有效之正本單據方為生效。倘未能出示任何一項，保修服務即無效，客戶須繳付服務費用。
- (5) 在保修期內維修更換後的所有零件、配置及附件，均屬本公司所有，本公司有權作出任何處理。
- (6) 吸塵機如需維修時，用戶須自行將產品送往維修中心及於修妥後自行取回。
- (7) 在下列情況下本保用證將自動失效，本公司有權拒絕維修該產品或向客人徵收所有維修費用。
 - i. 產品曾被非本公司人員修理或改裝。
 - ii. 產品曾被錯誤操作、疏忽使用(如因長時間沒取出電池而導致漏電池水)、輸入不合適電壓、人為損壞、因天災或意外等事件引致損壞。
 - iii. 不按照原廠提供之指示安裝或保養。
 - iv. 附於產品上的型號或產品編號曾被刪改或除去。
 - v. 擅自修改本保用證的內容。
- (8) 本公司將對任何於使用、維修或運送時引致之系統錯誤及資料流失、或因天然災害、意外事件造成之損失概不負責。
- (9) 本保用證的發出、終止及修改權均屬本公司所有，不作另行通知，就不明的情況或個案，經審查後，本公司有權發出或終止本保用證。
- (10) 本公司將不負責由於產品損壞而直接或間接引致之任何損失。
- (11) 此保用證只適用於香港特別行政區 / 澳門特別行政區範圍內。
- (12) 離島客戶須另付交通費。
- (13) 本公司及其授權之維修中心在維修或更換產品時，保留使用與上產品或功能相同的部分或全部再生零件之權利。
- (14) 如有任何爭議，本公司擁有絕對及最終決定權，而客戶必須完全同意遵守。
- (15) 本條款及細則將受香港法律管轄，所有因本條款及細則而產生或與其有關的糾紛概由香港法院解決。

